



RECHARGEABLE TELESCOPIC INSPECTION LIGHT 10W COB LED

MODEL NO: **LED187**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to
instructions

1. SAFETY

1.1. GENERAL

- ✓ Ensure the lamp is fully charged before initial use.
- ✗ **DO NOT** turn the lamp on when it is being charged.
- ✗ **DO NOT** shine directly into your, other person's or an animal's eyes.
- ✗ **DO NOT** allow children to use the lamp.
- ✗ **DO NOT** handle or move the lamp whilst it is being charged.
- ✗ **DO NOT** use the lamp if you suspect that the battery, the lamp casing or the cable is damaged. Consult your Sealey Stockist.
- ✗ **DO NOT leave battery in a discharged state, recharge battery immediately. Before storage, fully recharge the battery, subsequently recharge the battery at least once every six months of non-use.**

1.2. BATTERY SAFETY

- ☐ **WARNING!** To reduce the risk of burns or fire:
 - ✗ **DO NOT** Attempt to open, dismantle, modify or service the battery pack.
 - ✗ **DO NOT** Crush, puncture, short external contacts or dispose of in fire or water.
 - ✗ **DO NOT** Expose to temperatures above 40°C or below -10°C.
 - ✗ **DO NOT** Expose to direct sunlight for long periods of time.
 - ✗ **DO NOT** Expose to moisture.
- ☐ **WARNING! DO NOT** place the lamp face down while in use.
- ✓ Replace only with the battery pack designated for this product.
- ✓ Recycle or dispose of used battery as stipulated by local regulation.
- ✓ If the electrolyte in the cells gets on your skin, wash thoroughly with soap and water. If it gets in your eyes, rinse thoroughly with cool water and seek immediate medical attention.

2. INTRODUCTION

Telescopic rechargeable inspection light reaches into confined or hard-to-access areas for improved visibility. Telescopic Light; 1000lm (2hr runtime), 500lm (4hr runtime), Diffused Light; 600lm (2hr runtime), 300lm (4hr runtime) Top Spotlight; 100lm (7hr runtime). Opal diffuser provides even light distribution reducing shadows and glare. Magnetic base and integrated hook for hands-free operation. Built-in overcharge and over-discharge protection for safe, long-lasting performance. LED Charging indicator light shows charging progress and battery status. Supplied with a Type-C cable for fast and convenient charging.

3. SPECIFICATION

Model No:	LED187
Battery:	3.6 V Li-ion, 3000mAh
Charging Time:	3-4 hours
Electrical Class:	Class III
IP Rating:	IP65
LED Type:	COB
Lumen Output:	Telescopic Light; High - 1000lm, Low - 500lm Diffused Light; High - 600lm, Low - 300lm Top Spotlight; 100lm
Maximum Length:	286 mm
Minimum Length:	171 mm
Nett Weight:	0.23kg
Operating Time:	7 Hours (Max.)
USB Output:	Type C

LED187



IMPORTANT WARRANTY INFORMATION

The battery fitted to this lamp is considered to be a consumable item and its ability to accept a charge will reduce over time. We will provide Warranty against mechanical and electrical defect for a period of one year - this does not cover fair wear and tear. If the battery is not properly

Charged before first use, or regularly conditioned, its capacity will diminish. Under these circumstances we will not replace the battery regardless

Of whether the battery less than one year old.

4. CONTENTS/ FEATURES

CONTENTS	
1	LED 187
1	Type C USB Cable
1	User Manual

FEATURES	
1	ON/OFF Function button
2	Dual LED lights
3	Hooked handle
4	Magnetic Base

5. BATTERY

5.1. CHARGING INSTRUCTIONS

1. Connect the USB cable to the charging port. fig.1
2. Plug into a USB power source (adapter, laptop, power bank).

❑ **WARNING! DO NOT** turn lamp on whilst charging.


3. Charging indicator:

- Red = Charging
- Green = Fully Charged

4. Disconnect once fully charged.

5.2. USER TIPS


Use half brightness to extend battery life.



6. OPERATION


6.1. POWER ON/OFF (FIG.2)

- 6.2. First press: Press the power button once to activate the top light
- 6.3. Second press: Press the button again to switch on the main light at full brightness. At this stage, you may press the main light release button to extend the light and use its telescopic function if required
- 6.4. Third press: Press the button a third time to reduce the main light to half brightness.
- 6.5. Long press: Press and hold the button to turn on the main light and adjust the brightness continuously.
- 6.6. Press the button again to turn the light off.
- 6.7. As shown in Fig. 3, the light features a hooked handle for hanging and a magnetic base for hands-free attachment to metal surfaces.



7. MAINTENANCE

- 7.1. Clean the device using a dry or slightly damp cloth. Do not use harsh chemicals or solvents, as these may damage the surface or internal components.
- 7.2. Ensure the charging port remains free from dust and debris to maintain proper functionality.
- 7.3. **STORAGE**
Store the device in a cool, dry place, away from moisture and extreme temperatures.
- 7.4. Temperatures. Avoid placing heavy objects on the device to prevent damage.



8. DISPOSAL

- 8.1. Dispose of the product according to local regulations for electronic waste. Do not dispose of batteries in household waste.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR PURCHASE HERE



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



BATTERY REMOVAL

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd's Batteries Producer Registration Number (BPRN) is BPRN00705.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Jack Sealey Ltd t/a Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Jack Sealey (EU) Ltd t/a Sealey Group, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Tel: 01284 757500 • **Email:** sales@sealey.co.uk • **Web:** www.sealey.co.uk