


Space Warmer® Industrial Propane Heater 125,000Btu/hr

Model No. LPH125



Item	Part No.	Description
1	LPH125.01	Control Valve
2	LPH125.02	Filter/Diffuser
3	LPH125.03	Pilot Orifice
4	LPH125.04	Thermocouple
5	LPH125.05	Pilot Burner
6	LPH125.06	Regulator 17mm x 3000mm (3 metres)
7	LPH125.07	Ignitor
8	LPH125.08	Piezo Starter
9	LPH125.09	Axle
10	LPH125.10	Axle Bracket
11	LPH125.11	Handle
12	LPH125.12	Wheel, Fixed Plastic (Ø60 x 28 x Ø13mm Bore)

Item	Part No.	Description
13	LPH125.13	Valve Supply Tube
14	LPH125.14	Clamp
15	LPH125.15	Burner Manifold
16	LPH125.16	Burner
17	LPH125.17	Frame Assembly
18	LPH125.18	Top Plate
19	LPH125.19	Combustion Chamber
20	LPH125.20	Mounting Bracket
21	LPH125.21	Pilot Supply Tube
22	LPH125.22	Warning Sign for LPH125
--	LP55.44	Adaptor 8mm (Not Shown)



Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. See www.sealey.co.uk for the latest information.

Important: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person.



Jack Sealey (EU) Ltd t/a Sealey Group Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Jack Sealey Ltd t/a Sealey Group Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
 Tel: 01284 757500 • Email: sales@sealey.co.uk • Web: www.sealey.co.uk