




Parts Information:
Wall Fan 3-Speed 18" with Remote Control
230V
Model No: SWF18WR.V2



Item	Part No.	Description
1	SWF18WR.01	Brand Plate
2	SWF18WR.02	Screw
3	SWF18WR.03	Front Grille 18"
4	SWF18WR.04	Spinner For Blade
5	SWF18WR.V2-05	Fan Blade
6	SWF18WR.06	Nut For Rear Grille
7	SWF18WR.07	Rear Grille 18"
8	SWF18WR.08	Front Motor Cover
9	SWF18WR.09	Shaft Clip
10	SWF18WR.10	Screw
11	SWF18WR.V2-11	Motor
12	SWF18WR.12	Synchronous Motor (Internal 220-240v 50/60hz 4w)

Item	Part No.	Description
13	SWF18WR.13	Rear Motor Cover
14	SWF18WR.14	Screw
15	SWF18WR.15	Power Cord
16	SWF18WR.16	Screw
17	SWF18WR.17	Wall Bracket Hook
18	SWF18WR.18	Base Cover
19	SWF18WR.19	IC Panel
20	SWF18WR.20	Front Switch Housing
21	SWF18WR.21	Screw
22	SWF18WR.22	Nut
23	SWF18WR.23	Screw
24	SWF18WR.24	Base
25	SWF18WR.25	Remote Controller

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk