




8L PORTABLE COOL BOX 12V



Model No: DL166

Thank you for purchasing a Dellonda product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.



Refer to
instructions

Important Information

Please read these instructions carefully. Note the safe operational requirements, warnings & cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and/or personal injury and will invalidate the 12 month warranty. Keep these instructions safe for future use.

SPECIFICATION

- Model No: **DL166**
- Capacity: 8L
- Internal Dimensions: 14.6 x 27.5 x 17.7cm
- Weight: 2.6kg
- Power Rating: 12V - Cooling = 38W, Heating - 34W
- Temperature Range: Lowest Temp: 8°C based on ambient temp of 25°C, Heating by set-point thermometer 55°C +/- 10°C

SAFETY

The following should be read and understood before operating the product.

ELECTRICAL SAFETY

- **WARNING!** It is the user's responsibility to check the following:
- Check all electrical equipment and appliances to ensure that they are safe before using.
- Inspect power supply leads, plugs and all electrical connections for wear and damage.
- Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.
- **DO NOT** use worn or damaged cables, plugs or connectors.
- Ensure that any faulty item is repaired or replaced immediately by a Dellonda qualified technician.
- If the cable or plug is damaged during use, switch off the electricity supply and remove from use.
- **Important:** Ensure that the voltage rating on the appliance suits the power supply to be used and that the auxiliary plug is fitted with the correct fuse.
- **DO NOT** pull or carry the appliance by the power cable.
- **DO NOT** pull the plug from the socket by the cable.
- **WARNING!** Risk of electric shock. **DO NOT** clean the product with water while the power is still connected.
- **DO NOT** disassemble or replace components while the power is still connected.
- **DO NOT** operate the product if it's in a moist environment or its electrical components have come into contact with liquids.
- If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agents.
- Ensure the 12V plug is disconnected from the **DC** socket after the engine is turned off, or the cooler is not in use.
- Ensure the cords are inserted firmly to the sockets. If fitted loosely it can result in the over-heating and failing of the cord and socket.
- To prevent any electrical failure and fire keep the appliance away from flammable items and dampness.
- **DO NOT** use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

GENERAL SAFETY







- Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and/or personal injury and will invalidate the warranty.
- Children from age 8 years and above, persons with reduced physical, sensory, or mental capabilities those with lack of experience and knowledge can use the appliance, if they have been given supervision or instruction concerning use of the appliance in a safe way to understand the hazards involved. Children shall **NOT** play with the appliance.
- Cleaning and user maintenance on the appliance shall not be made by children without supervision.
- Prevent any obstructions to the fan. If the fan is blocked, it can overheat and cause fire. Avoid covering with towels or cloths.
- **DO NOT** disassemble the appliance,
- **DO NOT** rinse the cooler in water.
- **DO NOT** turn the cooler upside down.
- **DO NOT** drop the cooler.
- **DO NOT** store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Keep ventilation openings in the appliance enclosure or in the built-in structure, clear of obstruction.
- **WARNING!** When positioning the appliance, ensure the supply cord is not trapped or damaged.
- The appliance shall be disconnected from its power source during service and when replacing parts.
- Suitable for camping use.
- The appliance shall **NOT** be exposed to rain.

TO AVOID CONTAMINATION OF FOOD, PLEASE RESPECT THE FOLLOWING INSTRUCTIONS:

- Opening the door for long periods can cause a significant increase of the temperature in the compartment of the appliance.
- Clean regularly surfaces that can come in contact with food and accessible drainage systems.
- **DO NOT** overload the cooler and allow space between items to aid preservation of foodstuffs.
- If the refrigerating appliance is left empty for long periods, switch off, clean, dry, and leave the door open to prevent mould developing within the appliance.

OPERATION

- To obtain optimized cooling effect, we recommend putting in pre-chilled foods and drinks. It will take 2 or 3 hours to cool room temperature foods or drink.
- The cooler and warmer is not designed to heat cold food but to preserve hot food at a warm temperature. It can keep the food warm for hours.



1. Car engine needs to be running. First make sure the switch at the side of the cooler and warmer is in O position.
2. Insert the connector of the DC power cord into the DC 12V socket on the panel of the product.
3. Insert the plug of the DC power cord into the auxiliary socket in the car.
4. **COOLING:** set the power switch at the position of COLD. The green indicator will be on, indicating the unit is in cooling mode.
5. **HEATING:** set the switch at the position of HOT. The red indicator will be on indicating the unit is in heating mode.

ATTACH THE CARRY STRAP (SEE A, B, C, D ABOVE)

1. Pass the release end of the strap through the strap holder on the front and back of the device (see Fig. A).
2. Thread the loose end of the strap through the belt adjuster that this fits well (see Fig. B-D).

OPERATION IN EVENT OF AN ACCIDENT OR BREAKDOWN

- If the coolbox stops operating or makes any unusual noises, disconnect power supply, empty and contact Dellonda service.

MAINTENANCE

- **WARNING!** Disconnect from 12V DC supply. Maintenance is to be performed when necessary to maintain correct and safe performance. **DO NOT** use a faulty unit. Before conducting any maintenance work, turn off the product. All maintenance should be performed by an authorised service centre. Electrical repairs should **ONLY** be made by a qualified electrician. Contact an authorised service centre for repair.

CLEANING

- Turn off and unplug before cleaning. Regularly clean with a damp cloth, lukewarm water and mild detergent. **DO NOT** clean with abrasive materials or harsh chemicals. **DO NOT** spray water on the product, or allow water enter internal components. **DO NOT** open enclosures to clean electrical parts.

STORAGE

- Store the product upright in a cool, dry location. If you will not be using the unit for an extended period of time (more than a few weeks) it is best to clean the unit and dry it out completely. Disconnect the power cord when out of service.

END OF LIFE

- Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste Authority for recycling information.



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way.

Contact your local solid waste authority for recycling information.