



FLAP WHEELS

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Read instructions before use



Wear eye protection



Wear ear protection



Wear protective gloves



Wear a mask

1. INTRODUCTION

Aluminium oxide abrasive flap wheels ideal for finishing curved and intricate metal surfaces.

2. SAFETY

- ❑ **WARNING! If used incorrectly, this product can cause damage or injury to the operator. Ensure all instructions are read and understood, including the instructions of the tool the flap wheels are being used with.**
- ✓ Refer to the manufacturer's manual of the tool the flap wheel is being used with for information on correct mounting and use.
- ✓ Always wear safety glasses, ear protection, gloves and dust mask when using cutting or grinding wheels.
- ✓ Ensure the work area is well-ventilated.
- ✓ Use the correct type of wheel for the job you are doing.
- ✓ Keep your hands away from the wheel.
- ✓ Ensure the tool and flap wheel are compatible, and suitable for the task at hand by following all markings.
- ✓ Check the spindle speed of the tool is no higher than the operating speed marked on the wheel.
- ✓ Turn off the power and remove chuck keys etc. before changing the wheel.
- ✓ Disconnect from the mains or remove battery (if applicable) before making any adjustments to the tool.
- ✓ Inspect the wheel carefully before use. Make sure it is not cracked, chipped, or damaged in any way.
- ✓ Run the flap wheel up before use to ensure it is spinning correctly.
- ✗ **DO NOT** use flap wheels if they are cracked, chipped, or damaged in any way.
- ✗ **DO NOT** overload the wheel.
- ✗ **DO NOT** use the wheel if it is not spinning freely.

3. MAINTENANCE

- ✓ Replace the wheel when it is worn out or damaged.
- ✓ Store the wheel in a dry, cool place.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR PURCHASE HERE

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.
Important: No Liability is accepted for incorrect use of this product.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



sales@sealey.co.uk



www.sealey.co.uk